

# Clip Selection Guide – Architectural



SUBSTRATE TYPE	PANEL TYPE						
	Plywood	MDF	Particle Board	Acoustic Panel	Honeycomb	Fibrous Cement Board	Exterior Panels
<b>Steel frames eg. Steel</b>	PC-SF1 + PC-M1A PC-SF1 + PC-M2H PC-SF1 + PC-SM2 PC-SF1 + PC-SM2H	PC-SF1 + PC-M1A PC-SF1 + PC-SM2H	PC-SF1 + PC-M1A PC-SF1 + PC-SM2H + <b>Glue Thread</b>	PC-SF1 + PC-SM2	PC-SF1 + PC-SM2	N/A	N/A
<b>Timber battens or frames</b>	PC-F1A + PC-VM1 PC-F1A + PC-M2H PC-F1A + PC-SM2H	PC-F1A + PC-VM1 PC-F1A + PC-M2H	PC-F1A + PC-VM1 PC-F1A + PC-M2H	LP-F8 + LP-SM8	LP-F8 + LP-SM8	N/A	N/A
<b>Concrete + timber batten</b>	PC-F1A + PC-M2H PC-F1A + PC-SM2 PC-F1A + PC-SM2H	PC-F1A + PC-M2H PC-F1A + PC-SM2 PC-F1A + PC-SM2H	PC-F1A + PC-M2H PC-F1A + PC-SM2 PC-F1A + PC-SM2H	<b>Must use</b> Timber Batten + LP-F8 + LP-SM8	<b>Must use</b> Timber Batten + LP-F8 + LP-SM8	N/A	N/A
<b>Drywall eg. Gib Board</b>	LP-DF8 + LP-M8 LP-DF8 + LP-SM8	LP-DF8 + LP-M8 LP-DF8 + LP-SM8	LP-DF8 + LP-M8 LP-DF8 + LP-SM8	LP-DF8 + LP-SM8 with HMA (hot glue)	LP-DF8 + LP-SM8 with epoxy glue	N/A	N/A
<b>Plywood, MDF</b>	PC-F1A + PC-M1A PC-F1A + PC-M2H PC-F1A + PC-SM2 PC-F1A + PC-SM2H	PC-F1A + PC-M1A PC-F1A + PC-M2H PC-F1A + PC-SM2 PC-F1A + PC-SM2H	PC-F1A + PC-M1A PC-F1A + PC-M2H PC-F1A + PC-SM2 PC-F1A + PC-SM2H	LP-F8 + LP-SM8	LP-F8 + LP-SM8 with epoxy glue		

This Clip Selection Guide should be used as a general guide only. Please contact Fastmount Head Office for more detailed advice if required.

For overhead panels Fastmount strongly recommends a trial sample be made to prove compatibility of our systems with the panels and substrates in your project.